

# Interactieve televisie HD

Merkenlijst TV-codes



**TELE2**  
Born to be cheap

<b>A.R. Systems</b>	0037	0352	0556	0374	0455															
<b>Accent</b>	0037	0556																		
<b>Acer</b>	1339	1509	1644																	
<b>Acoustic Solutions</b>	1163	0178	1545	1523	1865	2055	1037													
<b>Adcom</b>	0625																			
<b>ADL</b>	1217	2022	0890	2195																
<b>Admiral</b>	0093	0361	0418	0087	0163	0264														
<b>Advent</b>	0876	1694	1613																	
<b>Adyson</b>	0068	0217	0216																	
<b>AEG</b>	0606	1556	1324	1037	1163	2239	2166													
<b>Aftron</b>	0860																			
<b>Agashi</b>	0216	0264	0217																	
<b>AGB</b>	0516																			
<b>Agef</b>	0087																			
<b>Aiko</b>	0037	0556	0371	0508	0433	0072	0361	0195	0264	0217										
<b>Aim</b>	0037	0556																		
<b>Airis</b>	1531	1833	2050	2089	2195															
<b>Aiwa</b>	0701	1913	1916	1908	1505															
<b>Akai</b>	0361	1326	1208	0371	0037	0433	0195	0508	0009	0072	0218	0714	0163	0516	0715	0602	0556	0548	0480	
	0217	0631	0216	0264	0178	0377	0606	1037	1908	0473	0648	0812	1259	1248	1935	1865				
<b>Akiba</b>	0218	0282	0455	0037	0556	0294														
<b>Akito</b>	0037	0556																		
<b>Akura</b>	0037	1645	0556	0668	1163	1770	1846	0412	0009	0218	0282	0264	1394	0714	1982	1989	1847	1983	1363	
	2239	1820	2289																	
<b>Alba</b>	0037	1037	0556	0714	0009	0418	0370	0235	0371	0668	0355	0218	0216	0247	0163	0487	0036	1913	1908	
	0443	1935	1997	1731	2050	2104	2056													
<b>AlfaView</b>	1206																			

<b>Alkos</b>	0508
<b>Allorgan</b>	0206 0294 0217
<b>Allstar</b>	0037 0556
<b>All-Tel</b>	0865 1269
<b>Amitech</b>	1281 0037 1468 1849
<b>Amoi</b>	1529 2342
<b>Amplivision</b>	0217 0370 0320
<b>Amstrad</b>	1890 0009 0516 0264 0371 0218 1394 0037 0556 0433 0412 0362 1037 0648 1913 1324 1982 1820
<b>Anam National</b>	0650
<b>Andersson</b>	1163 0556
<b>Anglo</b>	0009 0264
<b>Anitech</b>	0009 0068 0264 0037 0556 0282
<b>Ansonic</b>	0370 0037 0556 0009 0668 0374 0163 0292 0630 0247 1437 0428 1913 0104 1846
<b>AOC</b>	1588 2111
<b>Apollo</b>	0473
<b>Apro</b>	1846
<b>Arc en Ciel</b>	0501 0109 0196
<b>Arcam</b>	0216 0217
<b>Arçelik</b>	0714
<b>Ardem</b>	0486 0714 0633 0037 0556
<b>Arena</b>	0037
<b>Aristona</b>	0556 0037
<b>Art Mito</b>	0556 1820
<b>Arthur Martin</b>	0163
<b>ASA</b>	0105 0346 0070 0104 0087 0163
<b>Asberg</b>	0037 0556

<b>Asda</b>	2126
<b>Asora</b>	0009
<b>Astro</b>	0037
<b>Asuka</b>	0218 0217 0216 0264 0282 1913
<b>Atec</b>	1606 1728
<b>Atlantic</b>	0037 0556 0216 0206 0320
<b>Atori</b>	0009
<b>Auchan</b>	0163
<b>Audiosonic</b>	0009 0037 0374 0556 1800 0109 2050 0714 0715 2104 0217 0370 0264 0218 0486 0428 1983
<b>Audioton</b>	0217 0486 0370 0264 0428
<b>Autovox</b>	0087 0206 2172 0544 0349 0217 0247
<b>Avious</b>	1634
<b>Avol</b>	1820
<b>AVP</b>	1913 1908
<b>Axxent</b>	0009
<b>Axxon</b>	0714
<b>B&amp;D</b>	1217
<b>Baier</b>	0876 1324 2239
<b>Baird</b>	0109 0343 0192 0072 0073 0217 1208 1913 0606
<b>Bang &amp; Olufsen</b>	0620 0087 0275
<b>Barco</b>	0361 0163
<b>Basic Line</b>	0374 0037 0163 0668 0556 0009 0218 0282 0217 0455 1208 1037
<b>Bastide</b>	0217
<b>Bauer</b>	1615
<b>Baur</b>	0535 0195 0512 0037 0556 0361 0544 0349 1505 1010
<b>Bazin</b>	0217

<b>BBK</b>	1645
<b>Beaumarck</b>	0178
<b>Beko</b>	0714 0508 0486 0715 0037 0418 0428 0370 1800 0556 0606 0808 1652
<b>Belson</b>	1191 0894 2032
<b>Bennett</b>	0556 0037
<b>BenQ</b>	1212 1562 1574 1032
<b>Bensten</b>	1890 1326 1413 0894
<b>Beon</b>	0037 0556 0418
<b>Berthen</b>	0668
<b>Best</b>	0370
<b>Bestar</b>	0037 0556 0370 0374
<b>Bestar-Daewoo</b>	0374
<b>Bestwell</b>	1326
<b>Binatone</b>	0217
<b>Black Diamond</b>	0614 1037 0556 1163
<b>Black Star</b>	0247
<b>Black Strip</b>	0508
<b>Blackway</b>	0282 0218
<b>Blaupunkt</b>	0195 0535 0200 0327 0455 0170 0036
<b>Blauren</b>	0374
<b>Blue Media</b>	1728 1606
<b>Blue Sky</b>	0037 1324 1037 0714 1709 1521 1163 0487 1771 0668 0715 0625 1652 0451 1909 0556 0218 0282 0455 1913 1908 1191 0808 1363 1556 1916 0508
<b>Blue Star</b>	0282
<b>BlueH</b>	1776
<b>Boman</b>	1324

<b>Bondstec</b>	0247																			
<b>Boots</b>	0217	0009																		
<b>Bork</b>	1363																			
<b>Bosch</b>	0320	0327																		
<b>Boxlight</b>	0736																			
<b>BPL</b>	0037	0556	0282																	
<b>Bradford</b>	0180																			
<b>Brandt</b>	0625	0501	0109	0196	0287	0335	0343	0560	1588											
<b>Brandt Electronique</b>	0287	0335	0501																	
<b>Brimax</b>	1709																			
<b>Brinkmann</b>	0037	0556	0668	0418	0486															
<b>Brionvega</b>	0037	0556	0362	0087																
<b>Britannia</b>	0216	0217																		
<b>Brother</b>	0264																			
<b>Bruns</b>	0087	0428	0486																	
<b>BSR</b>	0550	0163	0294	0361																
<b>BTC</b>	0218																			
<b>Bush</b>	1037	1326	0614	1645	0660	0714	0037	0668	1652	0218	0163	0349	0009	0036	0371	0235	0282	0355	0361	
	0374	0264	0487	1208	0217	1556	0617	0698	0294	0556	1900	1913	1908	1163	0778	1259	1982	1248	0508	
	1916	1634	1682	1731	1166	0587	1869	1871	2056	2055	2053	2060	2050	2104	2214	1983	2212			
<b>Cameron</b>	2055	1523	1645	0556																
<b>Camper</b>	0037	0556	0486																	
<b>Canton</b>	0218																			
<b>Capsonic</b>	0264																			
<b>Carad</b>	0610	0037	0556	0668	1037															
<b>Carena</b>	0455	0037	0556																	
<b>Carrefour</b>	0036	0070	0037	0556																

<b>Cascade</b>	0009	0037	0556																
<b>Casio</b>	0037	0556	0163	0349	1913														
<b>CAT</b>	1682	2155																	
<b>Cathay</b>	0037	0178	0556																
<b>cello</b>	1820	1846	1770	1844	1845														
<b>Centrum</b>	1037																		
<b>Centurion</b>	0037	0556																	
<b>Century</b>	0087	0247																	
<b>CGE</b>	0074	0418	0247	0361	0370	0163	1913												
<b>Chimei</b>	1852																		
<b>Cimline</b>	0009	0235	0218																
<b>Cinetec</b>	2060																		
<b>Cinex</b>	0648	1166	1556																
<b>City</b>	0009																		
<b>Clarivox</b>	0418	0037	0556	0070															
<b>Clatronic</b>	0037	0370	0371	0714	0218	0264	0556	0217	0247	0009	0320	0648	1913	0606	1324	1163			
<b>Clayton</b>	1037																		
<b>CMS</b>	0216																		
<b>CMS hightec</b>	0217																		
<b>Combitech</b>	1908																		
<b>Concorde</b>	0009																		
<b>Condor</b>	0320	0037	0556	0370	0216	0009	0282	0247	0418	0630	0163	0264							
<b>Conia</b>	1645																		
<b>Conrac</b>	0808																		
<b>Conrad</b>	0037	0556																	
<b>Contec</b>	0216	0009	0036	0011	0264	0037	0556												

<b>Continental Edison</b>	0501	0109	0196	0287	0487														
<b>Cosmel</b>	0009	0037	0556																
<b>Crosley</b>	0087	0247	0074	0361	0163														
<b>Crown</b>	0009	0712	0370	0486	0037	0556	0487	0714	0606	0715	0418	1208	0672	0653	1037	1652	0668		
<b>CS Electronics</b>	0216	0218	0247																
<b>CTC</b>	0247																		
<b>CWR-Tech</b>	1324																		
<b>Cybertron</b>	0218																		
<b>Cytronix</b>	1298																		
<b>D.Boss</b>	1556	0037																	
<b>Daewoo</b>	0634	1849	2098	1203	0661	0037	0451	0374	1909	0556	0009	0216	0218	0217	1902	1908	0880	0178	0876
	1612	0865	0698	0714	0706	2275	2037												
<b>Dainichi</b>	0218	0216																	
<b>Daitsu</b>	1267																		
<b>Dansai</b>	0037	0556	0264	0508	0216	0009	0036	0217	1208										
<b>Dansette</b>	0412																		
<b>Dantax</b>	1981	0370	0486	1652	0714	1916	0606	0715	1908										
<b>Datsura</b>	1208																		
<b>Davis</b>	0736																		
<b>Dawa</b>	0037	0556																	
<b>Daytek</b>	1207	1376																	
<b>Dayton</b>	1207																		
<b>Daytron</b>	0009	0374	0037	0556															
<b>de Graaf</b>	1208	0044	0163	0548	0361														
<b>Decca</b>	0072	0516	0037	0556	0217	0621	1913	1908	1056										
<b>Dell</b>	1264																		

<b>Denko</b>	0264																		
<b>Denver</b>	1324	0037	0556	0606	1189	0587	1988	1634	1820	2050	1709	2139	2172	2197	2245				
<b>Desmet</b>	0320	0037	0556	0009	0087	0361													
<b>DGM</b>	1890	2022	2020	2239	2104	1435													
<b>Diamant</b>	0037	0556																	
<b>DiBoss</b>	0037	0556	1556																
<b>Digatron</b>	0037	0556																	
<b>Digihome</b>	1163																		
<b>Digiline</b>	0037	0556	0105	0668															
<b>DigiLogic</b>	0037	0556																	
<b>Digimate</b>	0890	2022	2020																
<b>Digital Device</b>	1606																		
<b>Digitek</b>	1521	1709	1771																
<b>Digitrex</b>	2056																		
<b>Digivision</b>	0361																		
<b>DigiX</b>	0880																		
<b>DiK</b>	0037	0556																	
<b>Dixi</b>	0009	0037	0556	0247	0217	0087													
<b>DMTECH</b>	1964	1338	2001	1898															
<b>Domeos</b>	0668	0037	1037																
<b>Domland</b>	0394																		
<b>Doric</b>	0349																		
<b>Dream Vision</b>	0673	1704																	
<b>DTS</b>	0009																		
<b>Dual</b>	0544	0349	0217	0343	0037	0556	0352	0394	0361	0163	1913	1202	0631	1163	1037	0778	2032	1324	1267

<b>Dumont</b>	0087	0104	0217	0070	0072	1913													
<b>Dunai</b>	0544	0163																	
<b>Durabrand</b>	0037	2126	1437	0556	1988	1652	2089												
<b>Dux</b>	0037	0556																	
<b>D-Vision</b>	0037	1982	0556																
<b>Dynatron</b>	0037	0556																	
<b>e:max</b>	1324	0606	1531																
<b>Easy Living</b>	1248	1259	2104	1709	1613	1217	0037	1376	2023	2005	0877	1166	1556	1666	2254	0282	1294		
<b>Edison-Minerva</b>	0487																		
<b>Eiki</b>	0735																		
<b>Elbe</b>	0630	0362	0610	0292	0370	0163	0037	0556	0218	0195	0217	0516	0361						
<b>Elbe-Sharp</b>	0516																		
<b>Elcit</b>	0087	0247	0516	0361	0163														
<b>Electrion</b>	0556																		
<b>Elekta</b>	0009	0037	0556	0264	0282														
<b>Elenberg</b>	1812	2055																	
<b>Elfunk</b>	1208	1037																	
<b>ELG</b>	0037	0556																	
<b>Elin</b>	0216	0037	0556	0105	0104	0548	0361	0349	0163	0009									
<b>Elite</b>	0218	0037	0556	0320															
<b>Elonex</b>	1776																		
<b>Eita</b>	0009	0068	0264	0216															
<b>Emco</b>	0247																		
<b>Emerson</b>	0714	0087	0247	0037	0556	0371	0070	0282	0320	0361	0451	1909	0486	0370	0163	0321	1913	0668	
<b>e-motion</b>	1709																		
<b>Emperor</b>	0282																		

<b>Emprex</b>	1789
<b>Epson</b>	0831
<b>Erae</b>	1191
<b>Erisson</b>	1682
<b>Erres</b>	0037 0556
<b>ESC</b>	0037 0556 0217
<b>Estèle</b>	0361 0163
<b>Etron</b>	0037 0556 0820 0009 0550 0163
<b>Eurofeel</b>	0264 0217
<b>EuroLine</b>	0037 2050
<b>Euroman</b>	0216 0264 0037 0556 0217 0370
<b>Europa</b>	0037 0556
<b>Europhon</b>	0037 0516 0163 0217 0556 0247 0361 0216
<b>Evesham</b>	1248 1163 1259 1719 1728 1606 1536
<b>Excel</b>	0037 0556
<b>Excello</b>	1037
<b>Expert</b>	0206 0163
<b>Exquisit</b>	0037 0556 0247
<b>Fagor</b>	0037 0556
<b>FairTec</b>	1191 1373
<b>Family Life</b>	0037 0556
<b>Fenner</b>	0374 0009
<b>Ferguson</b>	0073 0625 0287 0192 0335 0109 0560 0037 0556 0508 0343 0653 0104 0108 0361 1913 0548 0443 1037 1471 1916 1908 2053 2070 1935 1954
<b>Fidelity</b>	0163 0512 0361 1394 0037 0556 0371 0412 0216 0264 0544 1913 1908
<b>Filsai</b>	0217

<b>Finlandia</b>	1208	0346	0548	0361	0163	0072	0287	0343											
<b>Finlux</b>	0105 1556	0104 0629	0037 0473	0556 0418	0714 0606	0346 0621	1163 1202	0217 0808	0072 1248	0361	0163	0516	0715	0070	0087	0630	0631	0492	0480
<b>Fintec</b>	1982																		
<b>Firstline</b>	0037 0235	0556 1208	0374 1037	0668 1191	0714 0808	0451 1363	0163 1163	0009 1556	0294 1612	0321	0216	0247	0361	1909	0217	0630	0544	0349	0072
<b>Fisher</b>	0104	0217	0036	1208	0370	0087	0361	0163	0544	0349	0072								
<b>Flint</b>	0037	0556	0610	0072	0218	0455	0264												
<b>Force</b>	1163																		
<b>Formenti</b>	0163	0037	0556	0486	0216	0087	0320	0361											
<b>Formenti-Phoenix</b>	0216	0320	0361																
<b>Fortress</b>	0093	0087																	
<b>Fraba</b>	0037	0556	0370																
<b>Friac</b>	0009	0037	0556	0370	0610														
<b>Frontech</b>	0247	0264	0349	0361	0217	0009	0163												
<b>Fujicom</b>	1820	1709																	
<b>Fujimaro</b>	0865																		
<b>Fujitsu</b>	0683	0853	0206	0072	0217	0163	0009	0352	0037	0556	0361	0550							
<b>Fujitsu General</b>	0009	0217	0206	0163															
<b>Fujitsu Siemens</b>	1666	1298	1259	1248	1373	1163	0808	2174											
<b>Funai</b>	1817	1394	1037	1666	0668	0264	0294	0412	1505	1913	0714								
<b>Future</b>	0037	0556																	
<b>Gaba</b>	1037	0037	1183																
<b>Galaxi</b>	0037	0556	0361	0163															
<b>Galaxis</b>	0370	0418	0037	0556															
<b>Galeria</b>	0009																		
<b>GBC</b>	0361	0163	0009	0374	0218														

<b>GE</b>	0343	0735																	
<b>Geant Casino</b>	0163																		
<b>GEC</b>	0163	0361	0349	0037	0516	0556	0072	0217											
<b>Geloso</b>	0247	0009	0361	0163	0374														
<b>General Electric</b>	0343	0287																	
<b>General Technic</b>	0009																		
<b>Genexxa</b>	0218	0037	0556	0412	0163	0009													
<b>Gericom</b>	0865	1606	1423	1298	1206	1217	0880	0808											
<b>Gold</b>	1833	2023	1770																
<b>Goldfunk</b>	0668																		
<b>Goldhand</b>	0216																		
<b>GoldStar</b>	0037	0009	0370	0290	0377	0217	0247	0216	0556	0163	0361	0109	0606	0044	0714	0715	0455		
<b>Gooding</b>	0487																		
<b>Goodmans</b>	0634	0715	1259	1037	1248	0451	0037	0556	0714	0668	1909	0374	0036	0264	0072	0516	0009	0290	0487
	0371	0343	0235	0508	0480	0560	0217	0335	0218	1908	0630	0661	1900	0880	0587	1376	1985	1163	0178
	1841	1645	1682	2058	1720	2056	2055	2053	1719	1983	1531								
<b>Gorenje</b>	0370																		
<b>GPM</b>	0218																		
<b>Graetz</b>	0714	0361	0371	0163	0037	1208	0556	1163											
<b>Gran Prix</b>	0648																		
<b>Granada</b>	0037	0556	0226	0361	0072	0108	1208	0217	0036	0516	0508	0473	0335	0560	0163	0225	0343	0548	
<b>Grandin</b>	0037	0556	0009	0163	0610	0714	0715	0668	0374	0320	0282	0218	0455	1037	0865	1191	0880	1377	
	1556																		
<b>Gronic</b>	0217	0163																	
<b>Grundig</b>	0195	0508	1223	0535	1645	1582	0070	1037	0487	0037	0443	0706	0422	0556	0587	0009	0036	0370	1935
	1908	0630	1916	0178	1376	1800	0343	1981	1163	1869	2053	2239	2195	1259	2125				
<b>Grunkel</b>	1163																		

<b>Grunpy</b>	0180
<b>H&amp;B</b>	0808 2001
<b>Haier</b>	0698 1615 2212 0264 2134 1560
<b>Halifax</b>	0264 0216 0217
<b>Hampton</b>	0216 0217
<b>Hanimex</b>	0218 0294 1908
<b>Hanns.G</b>	1613
<b>Hannspree</b>	1351 1613 1776 2027 2214
<b>Hanseatic</b>	0037 0556 0349 0163 0361 0292 0544 0282 0394 0320 0634 0428 0370 0661 0009 0294 0217 0087 0377 0714 0808 0486 0625 2001 1964
<b>Hantarex</b>	0009 0037 0556 0516 0829 1338
<b>Hantor</b>	0037 0556
<b>Harsper</b>	0865
<b>Harwa</b>	1269
<b>Harwood</b>	0009 0412 0037 0556 0487
<b>Hauppauge</b>	0037 0556
<b>HCM</b>	0009 0412 0037 0556 0217 0218 0418 0282 0264
<b>Hedzon</b>	0556 0037
<b>Hema</b>	0217 0009
<b>Hemmermann</b>	0349 0544
<b>Hifivox</b>	0501 0109 0196
<b>Higashi</b>	0216
<b>Highline</b>	0264 0037 0556
<b>Hikona</b>	0218 1983
<b>Hinari</b>	1208 0037 0556 0009 0218 0036 0163 0355 0443 0487 0235 0294 0550 0264 1908
<b>Hisawa</b>	0282 0218 0455 0610 1908 0714

<b>Hisense</b>	1363	1556	2098	2037															
<b>Hit</b>	0087																		
<b>Hitachi</b>	1576 0563 0877	1772 0163 0217	0576 0343 2279	0578 2214	0719 0196	0225 1194	0349 0037	0744 0797	0556 0777	0361 0480	1037 0516	1484 0072	0441 0109	1645 0548	0044 0178	1163 0105	0634 0492	0473 0512	0036 0629
<b>Hitachi Fujian</b>	0108	0225	0576																
<b>Hitsu</b>	0009	0610	0455	0218															
<b>HMV</b>	0087																		
<b>Höher</b>	0714	1556	0865	1163															
<b>Home Electronics</b>	0606																		
<b>Horizont</b>	1617																		
<b>Hornyphon</b>	0037	0556																	
<b>Hoshai</b>	0218	0455	0282																
<b>Huanyu</b>	0374	0216																	
<b>Hugoson</b>	0890	1666	1217	2195															
<b>Humax</b>	1539																		
<b>HYD</b>	1376																		
<b>Hygashi</b>	0217	0216																	
<b>Hyper</b>	0009	0216	0217	0247															
<b>Hypersonic</b>	0361																		
<b>Hypson</b>	0037	0556	0714	0715	0264	0217	0282	0455	1908	1037	0668	0486							
<b>Hyundai</b>	0037	0556	0706	2139	1326	2058	1294	0876	1281	1468	1556	1532	1612	1376	1606	1694	0778		
<b>Iberia</b>	0037	0556																	
<b>ICE</b>	0264	0037	0371	0009	0556	0218	0217	0216											
<b>Ices</b>	0218	0216																	
<b>Ict</b>	0037	0556																	

<b>iDEAL</b>	1556
<b>ISonic</b>	1376 1513 1613
<b>Iiyama</b>	1217 0890 2159 2254
<b>Imperial</b>	0037 2090 0163 0370 2089 0074 0508 0556 0630 2197 0361 0349 0418 0247 0196
<b>Indiana</b>	0037 0556
<b>InFocus</b>	0736 1164 1206 1430
<b>Ingelen</b>	0487 0610 0714 0163 0361 1437
<b>Ingersoll</b>	0009
<b>Inno Hit</b>	0009 1037 0072 0037 0556 0218 0290 0217 0516 0247 0282 1163
<b>Innovation</b>	0037 0556 0068
<b>Innowert</b>	0865 1298
<b>Inspira</b>	1324 1556
<b>Interactive</b>	0037 0556 0087 0512 0275 0327 0163 0361 0370 0501 0109 0630
<b>Interbuy</b>	0009 0037 0264 0247 0068 0512 0556
<b>Interfunk</b>	0037 0556 0087 0512 0275 0327 0163 0361 0370 0501 0109 0349 0247 0200
<b>Internal</b>	0037 0556 0451 0374 1909
<b>International</b>	0216
<b>Intervision</b>	0282 0217 0455 0037 0068 0371 0377 0486 0370 0394 0487 0218 0163 0264 0247 0009 0556
<b>Ipure</b>	1694
<b>Irradio</b>	0009 0037 0556 0218 0247 0290 0371
<b>Isukai</b>	0218 0037 0556 0282 0455
<b>ITC</b>	0217 0361 0320
<b>ITS</b>	0037 0371 0218 0282 0264 0216 0009 0556
<b>ITT</b>	0163 2125 0480 0349 0361 0473 0548 0346 1208 0544 0610
<b>ITT Nokia</b>	0361 0548 0163 0473 0480 0349 0346 1208 0606 0610 0631
<b>ITV</b>	0037 0264 0556 0247 0374

<b>JDV</b>	1982
<b>Jean</b>	0036 1513 1511
<b>JEC</b>	0508
<b>JGC</b>	1709
<b>JMB</b>	0037 0634 0374 0556 0443 1908
<b>Jocel</b>	0712
<b>Jouge</b>	1435
<b>Jubilee</b>	0556
<b>JVC</b>	0653 1818 1153 0606 1653 0371 0731 0683 0036 0192 0218 0418 0093 0650
<b>Kaisui</b>	0218 0282 0037 0556 0216 0455 0217 0009
<b>Kapsch</b>	0163 0361 0206 0104
<b>Karcher</b>	0037 0556 0370 0610 0163 0282 0264 0778 0714 1556 0606 1982 2125
<b>Kathrein</b>	0556 0037 0880
<b>Kawa</b>	0371
<b>KB Aristocrat</b>	0163
<b>Kendo</b>	0610 0037 0556 0163 0512 0370 0377 0361 0428 0630 0235 0247 0362 0648 1037 1437 0486 1163
<b>Kennedy</b>	0163 0206 0361
<b>Kennex</b>	1037
<b>Keydo</b>	1702
<b>Keymat</b>	1771 1326 1504 1413 1890
<b>Kingsbrook</b>	1037
<b>Kingsley</b>	0216
<b>Kiss</b>	0800
<b>Kiton</b>	0556 0037 0668
<b>Kneissel</b>	0037 0370 0610 0630 0374 0556 0292 0362 1908
<b>Kobra</b>	1298

<b>Kolster</b>	0037	0556	0349	0247	0218								
<b>Konka</b>	0037	0556	0371	0714	0418	0218	2029						
<b>Kontakt</b>	0487												
<b>Korpel</b>	0037	0556											
<b>Korting</b>	0087	0370	0320										
<b>Kosmos</b>	0037	0556											
<b>Kotron</b>	0412	0264	1900										
<b>Koyoda</b>	0009												
<b>Kuba</b>	0349	0163											
<b>Kuba Electronic</b>	0349	0163											
<b>Kyoshu</b>	0412	0418	0264										
<b>Kyoto</b>	0163	0216	0217										
<b>L&amp;S Electronic</b>	0865	0714											
<b>LaSAT</b>	0486	0370											
<b>Lava</b>	1556												
<b>Lavis</b>	1037	0037	0163										
<b>Leader</b>	0009												
<b>Lecson</b>	0037	0556											
<b>Lemair</b>	0630												
<b>Lenco</b>	0009	1812	0037	0163	0374	0556	0104	0587	1037	1983	1376		
<b>Lenoir</b>	0009	1189											
<b>Lentec</b>	1531												
<b>Lesa</b>	0247												
<b>Levis Austria</b>	0037	0556											
<b>Lexsor</b>	1507												
<b>Leyco</b>	0264	0072	0037	0556	0294								

<b>LG</b>	1423	0178	0037	0370	1768	0377	0009	0556	0714	0001	0217	0216	0290	0163	0606	0109	0698	0715	0823
	0829	1556	1191	0247	0361	1681	1539												
<b>Liesenkötter</b>	0037	0327	0556																
<b>Lifetec</b>	0037	0668	1037	2001	0374	0009	0512	0556	0714	0218	0264	0683	1248	1259					
<b>Lloyd's</b>	0009																		
<b>Lodos</b>	1037	1163																	
<b>Loewe</b>	0512	0633	1884	0790	1836	0037	0556	0370	0087	0292	0362	0516							
<b>Logic</b>	2107																		
<b>Logik</b>	0011	1865	0371	0001	0880	1217	1037	1471	0282	2028	2029	1529	1645	2107					
<b>Logix</b>	0668	0037																	
<b>Luker</b>	1982	1985																	
<b>Luma</b>	0037	0361	0206	0163	0630	0556	0374	0009	0362										
<b>Lumatron</b>	0361	1937	2023	0206	0037	0556	0362	0163	0550	0217	0264	0073							
<b>Lux May</b>	0037	0009	0556																
<b>Luxor</b>	1163	0290	0361	0480	0492	0349	1208	0548	0163	0346	0473	1037	0217	0631					
<b>Madison</b>	0037	0556																	
<b>Magnadyne</b>	0087	0247	0516	0361	0163	0544													
<b>Magnafon</b>	0516	0216	0073																
<b>Magnavox</b>	0037	0556																	
<b>Magnum</b>	0648	0714	0037	0556	0715														
<b>Mandor</b>	0264																		
<b>Manesth</b>	0037	0556	0235	0217	0264	0320	0508	0294	0163	0361									
<b>Manhattan</b>	0037	0876	1556	0556	0668	1037	1267	0163	0778										
<b>Maqma</b>	1789	1298	1702	1709	1606														
<b>Marantz</b>	0037	0556	0412	1532															
<b>Marelli</b>	0087																		

<b>Mark</b>	0037	0556	0217	0216	0374	0009	0714	0715											
<b>Marks and Spencer</b>	1846	1847	2246	1770															
<b>Marquant</b>	2056																		
<b>Mascom</b>	1556	0556	0037	1871															
<b>Mastec</b>	1997																		
<b>Master's</b>	0037																		
<b>Masuda</b>	0371																		
<b>Matsui</b>	0037 0349	1163 0516	0556 0508	0487 1208	0443 0195	2007 0335	0009 0714	0235 0544	0011 1908	0355 1037	0072 0629	0036 1916	0217 1666	0294 0880	0371 2022	0433 1471	0361 2279	0455	0163
<b>Matsushita</b>	0650																		
<b>Matsuyama</b>	0587																		
<b>Maxim</b>	1982	1166	1556																
<b>Medialine</b>	1206	1964																	
<b>Mediator</b>	0037	0556																	
<b>Medion</b>	0714 1556	0808 1163	0037 2001	0668 2279	0556 1645	0512	0698	1908	1037	1437	1900	1248	1259	0245	1202	0631	0880	1916	1166
<b>MegaDrive</b>	1259																		
<b>Megas</b>	0610																		
<b>MEI</b>	1037	0037	0556																
<b>Meletronic</b>	0346 0451	0037 0634	0512 0361	0109 0195	0343 0068	0247 0661	0105 0714	0104 1652	0374	0009	0217	0480	0492	0216	0630	0349	0163	0287	0556
<b>Memorex</b>	0009																		
<b>Memory</b>	1983																		
<b>Memphis</b>	0072	0009																	
<b>Mercury</b>	0037	0009	0556																
<b>Merritt</b>	0548	0361	0163																
<b>Metz</b>	1533	0746	0388	0447	0367	0087	1163	0195	0535	0037	0556	0587	0275	0668	1037				

<b>Micromaxx</b>	0037	0556	0668	1037	0630	0808	1324	2001	0714		
<b>Microspot</b>	1614										
<b>Microstar</b>	0808										
<b>Mikomi</b>	1163	0744									
<b>Minato</b>	0037	0556									
<b>Minerva</b>	1248	0487	0535	0195	0070	0516	0108				
<b>Ministry of Sound</b>	1163										
<b>Minoka</b>	0412	0037	0556								
<b>Mirai</b>	1666	1852	2072	1651							
<b>Mirror</b>	1900										
<b>Mitsai</b>	1556										
<b>Mitsubishi</b>	0108	0512	0037	0087	0036	0535	0556	1208	1037	0868	
<b>Mitsuri General</b>	0163										
<b>Mivar</b>	0292	0290	0291	0370	0216	0609	0516	0217			
<b>Mogen</b>	1820										
<b>Monaco</b>	0009										
<b>Moree</b>	0037										
<b>Morgan's</b>	0037	0556									
<b>MTC</b>	0370	0349	0512	0163	0361						
<b>MTlogic</b>	0714	0037	2050								
<b>Multitec</b>	0037	0556	0486	0668	1037	1556	1982				
<b>Multitech</b>	0349	0009	0361	0486	0037	0370	0556	0217	0216	0247	0264
<b>Murphy</b>	0104	2005	0216	0072	0163	0361					
<b>Musikland</b>	0037	0218	0247	0556							
<b>Mx Onda</b>	1645	1983	1820								
<b>MyCom</b>	1376	0178									

<b>Myryad</b>	0556	0037																	
<b>NAD</b>	0865																		
<b>Naiko</b>	0037	1982	0606	0556															
<b>Nakimura</b>	0374	0037	0556																
<b>Naonis</b>	0361	0163																	
<b>Narita</b>	1982																		
<b>NEC</b>	0170	0036	0320	0455	0009	0374	0217	0037	0556	0011	2144	0245	1704	0653	0661	0701			
<b>Neckermann</b>	0037	0195	0370	1505	1010	0200	0556	0361	0163	0327	0418	0349	0087	0247	0217	0630	0320	0512	
<b>NEI</b>	0037	0556	0371	0163	1037														
<b>NEO</b>	0754	1324																	
<b>Neon</b>	1614	2058																	
<b>Neovia</b>	1206	0865	1964	1373	0876	1376	1384	1338	1191										
<b>Nesco</b>	0247	1908																	
<b>Nesx</b>	1614																		
<b>Netway</b>	2109																		
<b>Neufunk</b>	0037	0009	0556	0610	0218	0282	0714												
<b>New Tech</b>	0037	0009	0556	0343	0217														
<b>New World</b>	0218																		
<b>Nfren</b>	0800																		
<b>Nicamagic</b>	0216																		
<b>Nikkai</b>	0072	0218	0037	0556	0217	0264	0508	0216	0009	0036									
<b>Nikkei</b>	0714	2172																	
<b>Nobliko</b>	0070	0216																	
<b>Nogamatic</b>	0501	0109	0196																
<b>Nokia</b>	0361	0163	0480	0349	0548	0492	0473	1208	0374	0631	0606	0346	0320	0610	0109				
<b>Nordic</b>	0217																		

<b>Nordmende</b>	0109 1163	0501	0287	0196	0560	0343	0195	0037	0556	0335	0163	1259	1248	0714	2001	1413	0443	2007
<b>Norfolk</b>	0163																	
<b>Normerel</b>	0037	0556																
<b>Northern Star</b>	1206																	
<b>Novak</b>	0037	0556																
<b>Novatronic</b>	0037	0105	0374	0556														
<b>Novex</b>	1523																	
<b>Novita</b>	1384	0556																
<b>Nurnberg</b>	0163	0361																
<b>O.K.Line</b>	1037	1324	1556															
<b>Oceanic</b>	0163	0361	0294	1208	0563	0473	0548	0480	2001									
<b>Odeon</b>	0264	1812																
<b>Odys</b>	1812																	
<b>Okano</b>	0370	0037	0556	0264	0072	0009												
<b>OKI</b>	2125	1037																
<b>Olidata</b>	1376																	
<b>Omega</b>	0264																	
<b>Onei</b>	1163																	
<b>Onn</b>	1163	2055	2029	1709	2125	2166	0556	2126	2245	1770	2279							
<b>Onwa</b>	0371	0602	0218	0433														
<b>Onyx</b>	1709	1770																
<b>Opera</b>	0037	0556																
<b>Orava</b>	0361	1037																
<b>Orbit</b>	0037	0556																
<b>ORcom</b>	1504																	

<b>Orion</b>	2007 1916	2032 1908	2005 0880	0037 2001	0443	0355	0714	0235	2108	0556	0294	0320	0011	0009	0321	0264	0412	0516	0544
<b>Online</b>	0037	0218	0556																
<b>Ormond</b>	0668	1037	0037	0556															
<b>Orsowe</b>	0516																		
<b>Osaki</b>	0072	0218	0217	0264	0037	0412	0374	0355	0556										
<b>Osio</b>	0037	0556	0290																
<b>Oso</b>	0218																		
<b>Osume</b>	0036	0072	0218	0037	0556														
<b>OTIC</b>	1645	1983																	
<b>Otto Versand</b>	1505 0009	1010 0282	0036 0343	0093 0428	0512 0516	0037	0556	0535	0195	0544	0349	0361	0235	0109	0294	0226	0247	0320	0217
<b>Pace</b>	1908																		
<b>Pacific</b>	0037	2060	2126	0556	0714	1037	0443	1324											
<b>Packard Bell</b>	1556																		
<b>Pael</b>	0216																		
<b>Palladium</b>	0370	0037	0630	0714	0195	1505	1010	0200	0418	0556	0349	0247	0327	0087	0361	0163	0217	1982	
<b>Panache</b>	0556																		
<b>Panama</b>	0009	0217	0264	0216	0037	0556	0247												
<b>Panasonic</b>	0650	1636	1650	0226	1310	0361	0853	0367	0516	0037	0556	0163	0548	0001	1335				
<b>Panavision</b>	0037	0630	0556																
<b>Papouw</b>	0037	0556																	
<b>Pathe Cinema</b>	0163	0216	0320	0292	0349	0361	0370												
<b>Pathe Marconi</b>	0501	0109	0196																
<b>Pausa</b>	0009																		
<b>Perdio</b>	0072	0320	0163	0037	0216	0282	0556												
<b>Perfekt</b>	0037	0556																	

<b>Philco</b>	0087	0074	0418	0247	0361	0163	0370	0037	0556							
<b>Philex</b>	0163	0361														
<b>Philharmonic</b>	0217															
<b>Philips</b>	0556	0037	1744	0772	1246	1304	0195	0087	0760	0343	0595	0374	0009	0200	0361	1521
<b>Phocus</b>	0714	0037	1652	1800												
<b>Phoenix</b>	0037	0556	0370	0486	0163	0087	0072	0216	0320	0361						
<b>Phonola</b>	0037	0556	0087	0216												
<b>Pilot</b>	0556	0037	0712	0706												
<b>Pioneer</b>	1260	0760	1457	0037	0556	0428	0370	0343	0361	0109	0163	0287	0486	0512		
<b>Pionier</b>	0370	0486														
<b>Pixel</b>	1529															
<b>Plantron</b>	0037	0556	0264	0009												
<b>Play</b>	1267															
<b>Playsonic</b>	0714	0037	0217	1208	0715	1800	1652									
<b>Polar</b>	0037															
<b>Polaroid</b>	1523	1720	1645	2125												
<b>Policom</b>	0109	0196	0206	0275	0361	0163	0070	0074	0087	0501	0535					
<b>Poppy</b>	0009															
<b>Portland</b>	0374	0451	1909													
<b>Powerpoint</b>	0487	0037	0556	0698	0894	1770										
<b>Prandoni-Prince</b>	0247	0516	0361													
<b>Precision</b>	0217															
<b>Premier</b>	0860	2058														
<b>Prima</b>	0009	0264	0068	0412	1269	1507										
<b>PrimeView</b>	1606															
<b>Prinston</b>	1037															

<b>Prinz</b>	0072	0544	0349	0361															
<b>Profex</b>	0009	0163	0361																
<b>Profi</b>	0009																		
<b>Profilo</b>	1556																		
<b>Profitronic</b>	0037	0556																	
<b>Proline</b>	0037	0178	1545	0556	0625	2104	0634	0630	0321	0072	0621	1376	1513	1037	1531				
<b>Proscop</b>	0156																		
<b>Prosonic</b>	0037	0556	0370	1865	0374	0880	0371	0668	1376	2139	0714	0451	1820	0216	1890	2001	1324	1770	0217
	1556	2104	1709	1614	2090	0606	1507	2245	2197	2032	1787	2125							
<b>Protech</b>	0037	0556	0217	0009	0247	0349	0264	0418	0668	0282	0361	0163	0486	1037					
<b>Proview</b>	1645																		
<b>Provision</b>	0037	0556	1037	0714	1324	1531													
<b>Proxima</b>	0735																		
<b>Pye</b>	0037	0556	0087	0195	0374	0349	0412												
<b>Pymi</b>	0009																		
<b>QONIX</b>	1634																		
<b>Quadral</b>	0218																		
<b>Quadro</b>	2058	1326	0556	0037	0821	1163													
<b>Quasar</b>	0247	0865	0009																
<b>Quelle</b>	0037	1505	1010	0011	0501	0109	0512	0535	0544	0349	0195	0361	0036	0217	0247	0074	0327	0070	0104
	0105	0668	0556	0200	0264	0290	1037	0294	0346	0009									
<b>Questa</b>	0036																		
<b>Radialva</b>	0109	0218	0163	0037	0556	0287													
<b>Radiola</b>	0037	0556	0217																
<b>Radiomarelli</b>	0087	0516	0247	0037	0556														
<b>RadioShack</b>	0037	0556																	
<b>Radiotone</b>	0009	0037	0556	0428	0370	0418	0412	0648	0668	0264	1037								

<b>Rank</b>	0070
<b>Rank Arena</b>	0036
<b>RBM</b>	0070
<b>Recor</b>	0037 0556
<b>Rectiligne</b>	0037 0556
<b>Red Star</b>	1556
<b>Rediffusion</b>	0361 0548 0036 0346
<b>Redstar</b>	0037 0556
<b>Reflex</b>	0037 0556 1037 0668
<b>Relisys</b>	0865 0876 0877 1206 1207 1298 1376 0556 1612 1521 1645
<b>Reoc</b>	0714 0451 0634 1909
<b>Revox</b>	0037 0808 0556 0370
<b>Rex</b>	0206 0361 0630 0247 0550 0163 0264
<b>RFT</b>	0087 0292 0370 0428 0072 0264 0037 0556 0486
<b>Ricoh</b>	0037 0556
<b>R-Line</b>	0037 0556 0163
<b>Roadstar</b>	1037 0715 0009 0418 0037 0556 0714 0668 0218 0264 0282 1916 1437 1189 1900 1326
<b>Robotron</b>	0087
<b>Rodex</b>	0037 0556
<b>Rolsen</b>	1191 0037 0556 2098 2037
<b>Rover</b>	0877
<b>Rowa</b>	0264 0217 0009 0216 0587 0037 0556
<b>Royal Lux</b>	0370 0412 0335
<b>Rukopir</b>	0556 0037
<b>Saba</b>	0625 1166 0109 0560 0343 0287 0087 0163 0501 0516 0361 0498 0196 0335 0548 0650 0714 1588
<b>Sagem</b>	0610 0455 0282 0830 1313 0618 1596

<b>Saisho</b>	0235	0516	0009	0011	0217	0163	0264	0544	2022										
<b>Saivod</b>	1982	0037	0556	1163	1556	0668	0712	1037											
<b>Sakaï</b>	0163																		
<b>Salora</b>	0290	0349	0163	0361	0516	0548	1208	0480	0621	0037	0631	1166	1556	0778	1202	2125			
<b>Salsa</b>	0335																		
<b>Sambers</b>	0516																		
<b>Samsung</b>	0812	0618	0587	0556	0060	1235	0009	0037	0217	0370	0072	0766	0814	0264	0216	0290	0163		
<b>Sandra</b>	0216	0217																	
<b>Sansui</b>	0037	0556	0371	1935															
<b>Santon</b>	0009																		
<b>Sanyo</b>	1208 1037	0036 1163	0292	0011	0370	0072	0216	0217	0104	0009	0544	0163	0037	0108	0556	0486	0735	0170	1649
<b>Save</b>	0037	0556																	
<b>Saville</b>	1908																		
<b>SBR</b>	0037	0556																	
<b>ScanSonic</b>	1787																		
<b>Schaub Lorenz</b>	0548	0714	2172	0361	0349	0606	0486	0374	1191	1324	1194	1363	2032	1163	2125				
<b>Schneider</b>	0037 1909	0556 1908	0544 1982	0349 1916	0394 0070	0352 1617	0550 1556	0343 1324	0217 2128	0247	0371	0361	0218	0668	1037	0163	0648	0714	0451
<b>Scotland</b>	0163																		
<b>Scott</b>	1189	1983																	
<b>Seaway</b>	0634																		
<b>Seelver</b>	0556	1037	0037																
<b>SEG</b>	1037 1909	0037 0451	1163 2061	0556	1437	0668	0217	0487	0009	0349	0163	0264	0634	0036	0247	0362	0216	0361	0218
<b>SEI</b>	0087	1505	1010	0361	0163	0516	0544	0349	0294	0206	0037	0556							
<b>Sei-Sinudyne</b>	0206	0294	0516	1505	1010	0361	0544	0037	0556	0087									

<b>Seitech</b>	1217	1324																		
<b>Seleco</b>	0206	0361	0362	0163	0550	0630	0673	0371	0036	0264	0346									
<b>Sencora</b>	0009																			
<b>Sense</b>	1847																			
<b>Sentra</b>	0508	0218	0009	0550	0349															
<b>Serie Dorada</b>	0178																			
<b>Serino</b>	0610	0455	0216	0093																
<b>Sharp</b>	0093	1393	2214	0036	0491	0818	1819	0294	0653	0256	0516	0200								
<b>Shinelco</b>	2104																			
<b>Shintoshi</b>	0037	0556																		
<b>Shivaki</b>	0037	0556	0443	0451	0374	0178														
<b>Shorai</b>	0294																			
<b>Siarem</b>	0361	0163	0087	0516																
<b>Siemens</b>	0195	0535	0200	0327	0036	0037	0556	0361												
<b>Siera</b>	0037	0556	0587																	
<b>Siesta</b>	0370																			
<b>Silva</b>	0037	0556	0216	0361	0648															
<b>Silva Schneider</b>	2058	1556	2166	0648	2125															
<b>Silver</b>	0036	0037	0361	0556	0715	0163														
<b>SilverCrest</b>	1037	0037	0556																	
<b>SIM2 Multimedia</b>	0673																			
<b>Simz</b>	1820																			
<b>Singer</b>	0009	0087	0037	0556	0247	0335	0163													
<b>Sinudyne</b>	1324	0087	0235	0294	0361	0163	0516	0544	0349	1505	1010	0206	0037	0556	1908	0606				
<b>Skantic</b>	0361																			
<b>Sky</b>	0282	0880	1511	1612	1614	1513	0178	1613	1504	1606	1615	1709	1376	1776	1778	0661	0865			

<b>Skymaster</b>	0105
<b>Sliding</b>	0865 0880 1324 1377 0800 1556
<b>SLX</b>	0668
<b>Smaragd</b>	0487
<b>SmartVision</b>	1843
<b>Soemtron</b>	0865 1298
<b>Sogera</b>	0320
<b>Sogo</b>	1376 2050
<b>Solavox</b>	0361 0072 0163 0548 0550 0037 0556
<b>Sonawa</b>	0218
<b>Soniko</b>	0037 0556
<b>Sonitron</b>	1208 0370 0217
<b>Sonix</b>	1614
<b>Sonneclair</b>	0037 0556
<b>Sonoko</b>	0037 0556 0009 0264 0282 0217
<b>Sonolor</b>	1208 0163 1505 1010 0548 0361 0282
<b>Sontec</b>	0037 0556 0370 0294 0009
<b>Sontech</b>	1983
<b>Sony</b>	1505 1825 1651 1010 0011 1685 0036 0037 0556 0093 0170 0074
<b>Sound &amp; Vision</b>	0218 0374 0037 0556
<b>Soundwave</b>	0037 0556 0320 0418 0715 1846 1847
<b>Soyo</b>	1709
<b>Spectra</b>	0009
<b>Ssangyong</b>	0009
<b>Standard</b>	0037 2090 0556 1037 0218 0009 0217 0320 0374
<b>Starion</b>	1037

<b>Starlite</b>	0009	0361	0163	0037	0556	0264	0412												
<b>Starmedia</b>	2109																		
<b>Stenway</b>	0282	0218																	
<b>Stern</b>	0206	0550	0163	0361	0264	0630													
<b>Stevison</b>	1982	1556																	
<b>Strato</b>	0037	0556	0264	0009	1787														
<b>Strong</b>	1163	1037	0037	0556															
<b>Stylandia</b>	0217																		
<b>Sungoo</b>	2037																		
<b>Sunic Line</b>	0037	0556																	
<b>Sunkai</b>	0294	0355	0321	0455	0218	0235	0610	0037	0556	0487	0865								
<b>Sunny</b>	0037	1617																	
<b>Sunstar</b>	0371	0037	0556	0009	0264														
<b>Sunstech</b>	2001	2089	1964																
<b>Sunwood</b>	0037	0556	0009																
<b>Super</b>	1189																		
<b>Superla</b>	0516	0216	0217																
<b>SuperTech</b>	0009	0037	0556	0216	0218														
<b>Supra</b>	0374	0009																	
<b>Supratech</b>	2206																		
<b>Susumu</b>	0335	0218	0287																
<b>Sutron</b>	0009																		
<b>Swedx</b>	1606																		
<b>Swissline</b>	0247																		
<b>Swisstec</b>	1504	1612	1613	1614	1615	1513	1606	0880	1376	0865	1709	1776	1778	1849	1511	2104	2061		
<b>Sydney</b>	0216	0217																	

<b>Sylvania</b>	1394
<b>Sysline</b>	0037 0556
<b>Sytong</b>	0216
<b>T+A</b>	0447
<b>Tandberg</b>	0367 0630 0109 0196 0362 0361 0163
<b>Tandy</b>	0218 0072 0217 0247 0093 0163
<b>Targa</b>	0618 1191 1267 2245
<b>Tashiko</b>	0036 0217 0170 0216 0163 0361
<b>Tatung</b>	1720 0621 0037 1248 1556 1056 0556 0072 0516 0217 0011 0629 1908 1259 1191 1719 1324
<b>TCM</b>	0714 0808 2001 0037
<b>Teac</b>	1645
<b>TEC</b>	0217 0009 0247 0335 0361 0550 0037 0556 0163
<b>Tech Line</b>	0037 0556 0668 1437 1163
<b>Tech Lux</b>	1189
<b>Technema</b>	0320
<b>Technica</b>	1982 0621
<b>Technika</b>	2032 1865 2029 2104 1849 2212 1163 1983 0556 2125
<b>TechniSat</b>	0037 0556 0163 1267 2155
<b>Technisson</b>	0714 1652
<b>Techno</b>	0556 1037
<b>Technosonic</b>	0037 0556 1324 0880 1326 1890 1982 2032
<b>Technotrend</b>	1702 2155 1531
<b>Techvision</b>	1709 2032 1531 1771
<b>Techwood</b>	1163 1037
<b>Teckton</b>	1376
<b>Tecnimagen</b>	0556

<b>Teco</b>	1313	2109	1523	2180															
<b>Tedelex</b>	0217	0606	0037	0009	1208	0587	0556												
<b>Teiron</b>	0009																		
<b>TELE System</b>	0876	2125																	
<b>Teleavia</b>	0109	0501	0287	0196	0343														
<b>Telecor</b>	0037	0556	0163	0218	0217	0394													
<b>Telefunken</b>	0625 0821	0560	0074	0109	0343	0498	0262	0501	0287	0335	0073	0196	0037	0556	0486	0714	1556	0346	
<b>Telefusion</b>	0037	0556																	
<b>Telegazi</b>	0037	0163	0218	0264	0556														
<b>Telemeister</b>	0320	0037	0556																
<b>Telesonic</b>	0037	0556																	
<b>Telestar</b>	0037	2090	0556	1849	0412														
<b>Teletech</b>	0037	0556	0668	0009	0247	1037													
<b>Teleton</b>	0217	0275	0206	0550	0163	0349	0036	0361											
<b>Televideon</b>	0320	0361	0163	0216															
<b>Teleview</b>	0037	0556																	
<b>Temco</b>	0294																		
<b>Tennessee</b>	0037	0556																	
<b>Tensai</b>	0104	0218	0037	0556	0217	0294	0320	0009	0105	0374	0371	0377	0247	0715	0163	1037			
<b>Tenson</b>	0320	0009																	
<b>Tesla</b>	1037	0037	0668	0714	1652	0715	0630	0371	0696	2058	0556	0610							
<b>Tevion</b>	0037 2023	1248	1298	1645	1259	1556	1787	0556	0648	2032	0808	0865	0668	1771	0714	1037	2090	1800	
<b>Texet</b>	0217	0374	0009	0216	0218														
<b>Thes</b>	2036	1849																	

<b>Thomas</b>	1913																			
<b>Thomson</b>	0625	0560	0343	0287	0109	0501	0335	0196	0037	0556	0320	0349	0216	0361	1588	2128				
<b>Thorn</b>	0108 0374	0109 0070	0225 0508	0073 0501	0343	0361	1505	1010	0192	0074	0037	0535	0072	0556	0104	0011	0335	0512	0036	
<b>Thorn-Ferguson</b>	0104	0192	0335	0508																
<b>Time</b>	1702	1997																		
<b>Tiny</b>	1269																			
<b>Tiny Digital</b>	0660																			
<b>Tokai</b>	0072	0037	0556	0668	0163	0217	0374	0009	1037	0361										
<b>Tokaido</b>	1037																			
<b>Tokyo</b>	0216	0508																		
<b>Tomashi</b>	0282	0218																		
<b>Topline</b>	1037	0668																		
<b>Toshiba</b>	1508 0736	0508 1556	0714 0650	1656 1037	2060	1935	0070	1164	1582	1704	0217	0109	0195	0618	1916	1908	0009	0698	0037	
<b>Tosumi</b>	1982	1770																		
<b>Towada</b>	0349	0217	0361																	
<b>Toyoda</b>	0009																			
<b>Trakton</b>	0264																			
<b>TRANS-continentals</b>	0668	1037	1377	0865	0556	0037	0621	0486	0217											
<b>Transtec</b>	0216																			
<b>Triad</b>	0037	0556	0218	0009																
<b>Trical</b>	0036																			
<b>Trident</b>	0516	0217																		
<b>Trio</b>	1645																			
<b>Tristar</b>	0264	0218																		
<b>Triumph</b>	0516	0346	0556	0037																

<b>Tsoschi</b>	0282
<b>TVTEXT 95</b>	0556
<b>TWF</b>	1871
<b>Uher</b>	0037 0556 0206 0320 0374 0418 0486 0370 0480
<b>Ultra</b>	0192
<b>Ultravox</b>	0087 0374 0247 0216 0361 0163 0037 0556
<b>UMC</b>	1513 1606 1709 1614 1776 1849 2104 2061 2107
<b>Unic Line</b>	0037 0556 0473 0455 0349
<b>United</b>	0714 1983 0037 0715 0556 1916 1908 1037 0587 1982 1652 1820 1770
<b>Universal</b>	0714 0037 0556
<b>Universum</b>	1037 0037 1163 0346 0668 0105 0480 1437 0195 0473 0104 0535 0361 0011 0512 0247 0492 0370 0200 0418 0294 0036 0070 0163 0264 0556 0072 0630 0290 0074 0327 1505 1010 0544 0349 0217 0501 0109 0362 0631 0009 0170 0618 2174
<b>Univox</b>	0037 0556 0087 0163
<b>Utax</b>	0163
<b>V7 Videoseven</b>	1755 0178 0880 1376 1217 1666 1267 0618 1651 1505 2254
<b>Vanguard</b>	0037 0556
<b>Venturer</b>	0178 1545 1865
<b>Venus</b>	1326
<b>Vestel</b>	1037 1163 0556 0037 0668 0361 0163 0217
<b>Vexa</b>	0009 0037 0556
<b>Videologic</b>	0218 0216
<b>Videologique</b>	0216 0218 0217
<b>Videosat</b>	0247
<b>VideoSystem</b>	0037 0556
<b>Videotechnic</b>	0216 0320 0217 0374
<b>Videoton</b>	0361 0163



<b>Windy Sam</b>	0556
<b>World-of-Vision</b>	0880 0890 0865 0714 1298 0877 1606 1217 1614
<b>Woxter</b>	1531
<b>Xenius</b>	0634
<b>Xiron</b>	1981 1983
<b>Xomax</b>	1770
<b>Xoro</b>	0508 1217 1507 1789 1324
<b>Xrypton</b>	0037 0556
<b>X-View</b>	1191
<b>Yakumo</b>	1613
<b>Yalos</b>	1771
<b>Yamaha</b>	0650 0797 1526 1576
<b>Yamishi</b>	0282 0455 0218 0037 0556 0217
<b>Yokan</b>	0037 0556
<b>Yoko</b>	0217 0037 0556 0218 0264 0009 0370 1208 0216 0247
<b>Yorx</b>	0218
<b>Ytawai</b>	1531
<b>YU-MA-TU</b>	0037
<b>Yüsmart</b>	1613
<b>Zaapa</b>	1189
<b>Zanussi</b>	0206 0361 0217
<b>Zenor</b>	1208
<b>Zepto</b>	0556
<b>ZX</b>	1908